PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.



A:2PCS



D:2PCS



G:2PCS



M6*35 **J:24PCS**



B:2PCS



C:2PCS



E:2PCS



F:1PC



H:1PC



I:1PC




M6*30 **K:12PCS**



L:1PC

Do not fully tighten bolts until assembly is complete.



Do not fully tighten bolts until assembly is complete. **ASSEMBLY INSTRUCTIONS** TREVISO RATTAN 3 PIECE BISTRO SET(154913)