

ASSEMBLY INSTRUCTIONS





Item NO.: 141683

Carefully remove all parts from the box and lay on a flat surface.

Note: Electrical wire is connected continuously through the poles.

Please DO NOT pull wire during unpacking, it could lead to poor connectivity.

IMPORTANT NOTICE:

This plastic ring protects cable avoiding being damaged during transportation, please throw them away, and keep out of reach of children

Be careful not to twist or damage power cord when assembling the light.

- According to the assembly sequence, Screw part C into part D and tighten.
- ②. Screw part D into part E and tighten.
- 3. Screw part E into Part F, and tighten
- ④. Screw part F into Part G, and tighten

To fit the shade: Remove the shade ring (A) from lamp holder (C) and fit the shade (B). Position the shade over the lamp holder and refit the shade ring to secure in place. Take care not to overtighten as may cause damage to the fitting.


ES MAX 42W (Bulb not included)

The wattage indicated must not be exceeded.









Warnings

- * Ensure the plug is not connected to any power supply and read instructions before assembly.
- * To avoid the risk of fire, do not exceed the recommended wattage of bulbs as indicated on the fitting.
- * Ensure the floor lamp is placed on a stable, solid surface and under no circumstances must it be covered with any material
- * The shade and lamp may become very hot in use. Switch off and allow 10 minutes to cool before replacing bulb, adjusting, or cleaning (using a dry cloth only do not use liquid or abrasive cleaners).
- * The assembly of this floor lamp is not suitable for persons under 18 years of age. Keep small parts out of reach of children.
- * This lamp is for indoor use only.